

NEW:

derma Litecheck® UV Multimedia

now also available with integrated USB camera

EUR 442,00

plus shipping costs outside Germany and legal VAT

- **Operation: e.g. with Windows 10 (Camera and Media Player)**
- **Editing of films (cut etc.) with common Windows-programmes**

Multimedia device with integrated USB camera,
encl. connecting cable CMOS, 3.14 Megapixel, 80° V5 Fixfokus, USB 2.0

Initiating operation:

- Insert mains plug into the socket, which is located at the left side of the device. Switch on (switch lights up red).
- Remove protective cap from camera eye, which is integrated in the glass plate under the electronic.
- Insert the USB cable into the corresponding socket on the back side of the device.
- Connect the USB cable to your computer
- Sound Signal/screen note: „USB camera recognized/installed“
- Example Windows 10: open programme „Camera“

NEW:

derma Litecheck® UV Multimedia

now also available with integrated USB camera

visualize and communicate

by means of the smart desk solution made by Dermalux®

Examples for application:

scientific studies
design of lectures
animation with pictures and/or videos
live-switch via Skype
presentations by laptop/beamer/monitor/TV
large projections

personnel training
trade fair
congress
group training
prove of evidence
customer presentation
sales meetings

archiving of data
long-term investigations

and much more...

